1	Before driving	1-5.	Refueling Opening the fuel tank cap	ź8
1-1.	Key information	1-6.	Theft deterrent system	
	Keys 20		Engine immobilizer system	
1-2.	Opening, closing and locking the doors and trunk		Theft prevention labels (U.S.A.)	75
	Smart access system with push-button start	1-7.	Safety information	
	Wireless remote control35		Correct driving posture	76
	Doors		SRS airbags	78
	Trunk 41		Front passenger occupant classification system	39
1-3.	Adjustable components		Child restraint systems	94
	(seats, mirrors, steering wheel)		Installing child restraints	98
	Front seats			
	Driving position memory (driver's seat)45	2	When driving	
	Seat position memory (front passenger's seat) 49	2-1.	Driving procedures	
	Head restraints51		Driving the vehicle10	30
	Seat belts 52		Engine (ignition) switch1	16
	Steering wheel 58		Automatic transmission 12	2C
	Anti-glare inside rear view		Turn signal lever12	28
	mirror		Parking brake 12	29
	Outside rear view mirrors 01		Horn13	3C
1-4.	Opening and closing the windows and moon roof			
	Power windows 63			
	M(			

2-2.	Instrument cluster				
	Gauges and meters131	3 Interior features			
	Indicators and warning lights	3-1.	Using the air conditioning system and defogger		
2-3.	Operating the lights and windshield wipers  Headlight switch		Automatic air conditioning system		
	Windshield wipers and washer		Audio system types		
2-4.	Using other driving systems  Cruise control		Playing back MP3 and WMA discs		
	Intuitive parking assist		Using the AUX adapter		
2-5.	Driving information  Cargo and luggage		Using the interior lights Interior lights list		

Using the storage features	4 Maintenance and care
List of storage features	1 Idintendice and care
love box 231	
ole box232 nead console233	4-1. Maintenance and care
ders234 olders/	Cleaning and protecting the vehicle exterior
kets236	Cleaning and protecting the vehicle interior
nterior features	
s 237	4-2. Maintenance
or 238	Maintenance requirements 274
239	General maintenance 276
hes 240	Emission inspection and
243	maintenance (I/M)
iter 244	programs 279
245	4-3. Do-it-yourself maintenance
246	
248	Do-it-yourself service precautions
extension 249	Hood
251	Positioning a floor jack
252	Engine compartment286
253	Tires
ener 256	Tire inflation pressure
262	Wheels
	Air conditioning filter 317
	Electronic key battery 320
	Checking and replacing
	fuses 322
	Headlight aim336
	Light bulbs

5-1.	Essential information
	Emergency flashers
	If your vehicle needs to
	be towed 345
	If you think something
	is wrong
	Fuel pump shut off system 352
	Event data recorder 353
5-2.	Steps to take in an emergency
	If a warning light turns on or a
	warning buzzer sounds 355
	If a warning message is
	displayed365
	If you have a flat tire 379
	If the engine will not start $388$
	If the shift lever cannot be
	shifted from P
	If you lose your keys 390
	If the electronic key does not
	operate properly 391
	If the vehicle battery is
	discharged
	If your vehicle overheats 397
	If the vehicle becomes
	stuck 400

When trouble arises

/ehic	le spe	ecifica	ations
	/ehic	ehicle spe	ehicle specification

Maintenance data

6-1. Specifications

6-2.	Customization Customizable features 428		
6-3.	Initialization Items to initialize		
7	For owners		
	Reporting safety defects for U.S. owners		
	Seat belt instructions for Canadian owners (in French)		
	Index		
Abb	reviation list440		
Alphabetical index442			
What to do if453			